



## Installation Guide: *Hatches and Rodholders*

### **Tools Needed:**

Electric Drill  
3/16" Bit  
Rivet Gun  
3/16" Rivets  
Rotozip or Jig Saw  
Flat File  
Sharpie Pen

### **STEP 1: DETERMINE LOCATIONS**

Choose a flat area for hatches or rodholders. Be sure there is enough room inside the kayak for the flushmount rodholders to fit without hitting the bottom of the boat. Place the foam gasket (included) on the selected area and trace the inside edge with a sharpie pen.

### **STEP 2: INSTALL HATCHES AND RODHOLDERS**

- A.) Use the rotozip to cut out the marked shape, or drill a hole with the drill and use a jig saw to cut out the shape.
- B.) Use the flat file to fine tune so that the item fits perfectly.
- C.) Mark each hole with a sharpie pen, remove the item and drill each hole.
- D.) Place the item back in place with the gasket and put a rivet in each hole upside down to keep the gasket from shifting.
- E.) Attach the item one rivet at a time while leaving the rest upside down in their holes.

**This concludes your installation. Thank you for shopping with HookedOnKayaks.com. Please give us a call if you have any other questions or problems at (562) 592-0800 Good Luck!**