



Installation Guide: *Paddle Clips*

Tools Needed:

Electric Drill
3/16" Bit
Rivet Gun
Marine Goop
(4) 3/16" Rivets
Sharpie Pen

STEP 1: DETERMINE LOCATIONS

Decide if you want your paddle on the left or right side of the boat. Next take a paddle clip and hold it onto the side of the boat on a flat area. Place it near the back of the seat area and mark the holes with a sharpie pen. Place the second paddle clip about 24" forward and mark with a sharpie.

STEP 2: INSTALLING THE PADDLE CLIPS

Drill holes on the marks with a 3/16" bit. Put a gob of marine goop over each hole and attach the paddle clips using rivets making sure the clips fold back toward the stern. If it is possible to access the back sides of the paddle clips it is recommended to add some additional marine goop to the back of the rivets.

This concludes your installation. Thank you for shopping with HookedOnKayaks.com. If you have any additional questions or problems please call us at (562) 592-0800 Good Luck!